

SAR values

The specific absorption rate (SAR) of the SHIFT6mq is well below the legal limits. The energy, which the human tissue takes up is determined in two different test scenarios.

SAR values according to EN 62209-1
0.29 W/kg (at the ear)

SAR values according to EN 62209-2 (dist.: 0.5 cm)
1.2 W/kg (on the body)

You can reduce the value even further,
using speakers/headset.

Information at: shiftphones.com/6mq-sarwert



Deposit | upgrade | return

There is a deposit in your SHIFT6mq box certificate. If you cannot or do not want to use your device any longer (after many years), simply send it to us to Falkenberg together with the certificate. You will get your device deposit back and we will take care of second life usage or professional recycling of your SHIFTPHONE.

More information lives at:
shiftphones.com/pfand



You can switch to another SHIFTPHONE
or upgrade to another technology from SHIFT.

We determine the value of your old device and offer you an attractive buyback price. You can find information about the upgrade here:
shiftphones.com/upgrade



It sometimes happens that the goods ordered do not meet expectations. You can withdraw from the purchase contract for the first 14 days after receiving your SHIFTPHONE. We understand that and are not angry with you at all.

You can find information on returns at:
shiftphones.com/retoure



Not for the bin!



It is important to us to produce as little waste as possible. We therefore ask you not to dispose of your SHIFTPHONE in the residual waste, but to send it back to us.

The packaging is not rubbish either. Only recycled paper, unlaminated cardboard and small amounts of environmentally conscious printing ink are used. Keep this packaging well! You will need it if you want to ship the device and it is also required for a full refund of the device deposit.

More about this:
shiftphones.com/packing



You are welcome!

With your SHIFTPHONE you are now part of the SHIFTFamily. We look forward to accompanying you and being there for you if you have any questions.

We have a team of competent and extremely friendly people who are happy to take the time for your support inquiries.

You can get direct help at:
shiftphones.com/help



Or do you want to get to know us first?
shiftphones.com/support-hello



SHIFT GmbH

If you would like to visit us, you are welcome to drop by the SHIFT headquarters after making a brief appointment:

SHIFT GmbH
Campus 7
34590 Falkenberg
+49 5683 2379900

To prevent your SHIFTPHONE from getting homesick, feel free to contact us on our social media channels regularly and keep an eye out for events and promotions.



Here I am:

YOUR SHIFT6mq

Dear SHIFT6mq user

It is very nice to finally be with you. Just like you, I am unique, too. You probably won't find a device like me anywhere in the world.

I consist of many high quality modules that you can replace yourself with the enclosed screwdriver. When choosing my raw materials, great care was taken with the environment and I was manufactured under respectful conditions.

Here Carsten and Samuel, the founders of SHIFT, welcome you personally:

shiftphones.com/6mq-welcome



Scope of delivery

Your new SHIFTPHONE doesn't come alone, it brings you the following:


- a battery with 3850 mAh
- this booklet that you are holding in your hands
- a T3 screwdriver (all screws in your SHIFT6mq are identical - and all of them own a Torx T3 drive)
- your deposit certificate
- a bulletproof glass
- a black bumper

First steps


With these first three steps you can put your new SHIFT6mq into operation. First remove the protective cover. Now you can reach behind the back and find the small notch at the lower end and detach it from the locking hooks (Fig. 1).



In order to be able to insert your SIM and memory cards, you must first remove the battery (Fig. 2). The slots for two nanoSIM cards and a microSD card are on the upper edge (Fig. 3). You can feel the SIM cards click into place. If you want to use a microSD card, please format it as portable storage.



Then you can reinsert the battery and lock the device. Now your SHIFT6mq can be started by pressing the power button. You will find detailed instructions for the first and following steps here: shiftphones.com/6mq-firststeps



Battery care

In order to be able to use your battery as long as possible, you should pay attention to the following things:

- Charger with 2.0 - 2.5 A at 5 V per USB socket
- It is best to use a charger with a USB-C socket, because more energy can be transferred
- use charger with intelligent charging electronics, that your battery is charged quickly and gently.

Data backup

Loss of data is annoying. We recommend that you backup regularly. If your SHIFTPHONE is lost, stolen or damaged, you can fall back on it.

ShiftOS

Your SHIFTPHONE runs on the Android™ 10 operating system, which we call ShiftOS due to our in-house adjustments. By default, we deliver our ShiftOS in the G version, which includes all known Google apps and services.

In addition, however, you have the option to switch to our L version (L = Light), that runs without Google services.

You can find out more on: shiftphones.com/6mq-shiftos



SHIFT6mq supports Qualcomm® aptX™ HD. Google and Android are trademarks from Google LLC. Including the Google app and Google Chrome™.